GUI for a Microgrid's Control System

Shouran Mu supervised by Edwin Mora








Agenda



- 1 Introduction
- 2 Methodology
- 3 Implementation
- 4 Outlook

Introduction - Motivation





Introduction - Challenges



GUI designed in LabVIEW

How to present comprehensive information with GUI?


2 OPC Unified Architecture

How to build communication based on OPC UA?

Raspberry Pi as Bridge
How to coordinate different communication protocols?


Methodology - Main Topology






Methodology – Transmission Protocol






Implementation - RT-LAB Project





Implementation - Matlab Simulink





Implementation – Service Configuration



```
param list = read param from txt()
server = Server()
 start opc port in pi
opc_url = "opc.tcp://" + Local_IP + ":4840/"
server.set_endpoint(opc_url)
 register namespaces for 4 diff devices
namespace_list = ["DS001", "DS002", "Battery", "Photovol"
object list = create namespace for object(namespace list
#start opcua server
server.start()
print("OPCUA Server started at {}".format(opc url))
```

Start OPC server at port 4840 locally

Send UDP packet to server with host IP & port 8002

Load the parameters name from txt file e.g. GasLevel, P, f, kf, tf, kP, tP...

Create namespace for each device e.g. DS001, DS002, BT001, PV001

Bind UDP server with port 8001 for listening

Implementation – Service



```
Read value by specified
kf var = server.get node("ns=2;i=8").get value()
                                                                 namespace and node id
tf_var = server.get_node("ns=2;i=9").get_value()
kP_var = server.get_node("ns=2;i=10").get_value()
tP var = server.get node("ns=2;i=11").get value()
Kp_var = server.get_node("ns=2;i=12").get_value()
Ki var = server.get node("ns=2;i=13").get value()
print("changed kf_node: ", kf_var, " tf_var: ", tf_var, " kP_
                                                                 Pack and send updated value to
                                                                 server OP4510 in UDP packet
######## send the changed value back to op4510 ##########
                                                                 for simulation
client.sendto(struct.pack('ddddddd',kf_var,tf_var,kP_var,tP_var)
receive data, client address = server socket.recvfrom(80)
                                                                  Receive simulation results from
receive data = struct.unpack('dddddddddd', receive data)
                                                                  server OP4510
#print("received data from UDP : ", receive data)
```


Implementation – Service



```
######### prepare the param list ##########
                                                             data_list=[]
      Unpack and prepare the
                                                             data list.append(randint(0,100))
      values for building parameters
                                                              for item in receive_data:
                                                                 #2 digits after dot
                                                                 data_list.append(float('%.3f' % (item)))
                                                             #insert some missing parameters
                                                             #Pmin, Pmax
                                                             data_list.insert(3, 500)
        Insert some constant values
                                                             data_list.insert(4, 500)
         (which are not provided by RT
                                                             #opMode
        server) to build parameters list
                                                             data_list.insert(5, 0)
                                                             #print ("parametsers data : ", data_list)
                                                             ########## send updated param_list to Labview ##
                                                             for object item in object list:
                                                                 var list = object item.get variables()
Set complete parameters list to LabVIEW
                                                                 for var in var list:
to display on each control panel
                                                                     index = var list.index(var)
                                                                     var.set_value(float(data_list[index]))
```


Implementation - LabView Project






Implementation - Main Control Panel






Implementation - Main Control Panel






Implementation - Sub Control Panel






Implementation - Example





Outlook – to be better...





Question about ...



